

Bow number placement:

Bow numbers must be applied on each side of the hull no more than 12 inches from the bow and 2 inches below the gunwale. This means that a perpendicular line extended from the gunwale 12 inches from where the stem intersects the deck touches or intersects the forward numeral. Numbers must be oriented and spaced in a legible manner. See diagram below.

